


# BIENESOL

## BALCONY ALL-IN-ONE ESS CUBE SERIES



# Contents

|                                  |    |
|----------------------------------|----|
| Introduction                     | 3  |
| Symbols Used in This Guide       | 4  |
| System Introduction              | 4  |
| Product description              | 4  |
| Unboxing Guide                   | 5  |
| Product Dimension                | 6  |
| Electrical Function              | 7  |
| LED Display                      | 9  |
| Installation                     | 9  |
| Heavy Object Handling Safety     | 9  |
| Assembly Process                 | 10 |
| Power On                         | 12 |
| Monitoring System                | 12 |
| Operating Mode                   | 15 |
| Fault Codes and Trouble Shooting | 18 |
| Technical Parameters             | 21 |
| Maintenance Guide                | 23 |
| Routine Maintenance              | 23 |
| Energy Storage Unit Maintenance  | 23 |
| Storage and Disposal             | 24 |
| Warranty                         | 24 |
| Dealer Responsibilities          | 25 |

## Introduction

Thank you for choosing BIENESOL products. We hope our products can meet your needs for renewable energy. We also appreciate your feedback on our products.

## Safety Introduction

### Disclaimer:

Read all safety guidelines, warnings and other product information in this manual carefully, and read any labels or stickers attached to the product before using. Users take full responsibility for the safe usage and operation of this product. Familiarize yourself with relevance regulations in your area. You are solely responsible for being aware of all relevance regulations and using BIENESOL products in a way that is compliant.

Keep this manual for future reference.

This equipment should be used in an environment that complies with the design specification. Failure to do so may result in equipment failure, malfunction or component damage, personal safety accidents, property losses, etc., which are not covered by the equipment quality assurance.

### Our company does not assume any responsibility for the following situations:






- Operation not within the specified operating conditions in this manuals.
- Installation and use environments outside the limits of relevant international or national standards.
- Unauthorized disassembly or modification of the product software code.
- Failure to follow the operating instructions and safety warnings in the product manual.
- Damage to the device caused by abnormal natural conditions (force majeure, such as earthquakes, fires, storms, etc. ).
- Transport damage caused by the customer.
- Damage caused by storage conditions that do not meet product requirements.

### Dangers:

- In the event of a fire, evacuate the building or equipment area and press the fire alarm or call the fire department. Reentering a burning building is strictly prohibited under any circumstances.
- Do not disassemble or modify the energy storage unit without permission.

## Symbols Used in This Guide

Thank you for choosing BIENESOL products. We hope our products can meet your needs for renewable energy. We also appreciate your feedback on our products.

| Symbol   | Explanation  |
|--|--|
|   | Comply with EU Declaration of Conformity   |
| <b>RoHS</b>  | Comply with RoHS directive   |
|   | Read this manual before installation, operation and maintenance  |
|   | Must not be disposed of as household waste   |
|   | This symbol indicates the presence of high voltage and risk of electric shock  |
|  | To avoid electric shock or injury, do not touch or use the inverter at least 3 minutes after turning it off or disconnecting it from other power grids |

## System Introduction

### Product Description

This user manual describes the energy storage system performance specification, operating conditions and warning information. It applies only to this product.

The energy storage system consists of hybrid inverter, battery packs and a wireless communication module. Its primary function is to convert AC power into DC power and stored in the battery pack. When it







needs, convert DC power from battery pack to AC power to the load or grid. This system is equipped with an energy management system (EMS) and a battery management system (BMS) to monitor data, provide early warnings and control of the battery units. This system can be used for both off-grid and grid-connected hybrid solar systems, suitable for home and balcony applications.

This system must be used in conjunction with BIENESOL Cube 2700-E energy storage battery pack.

## Unboxing Guide


### What's in the box

Before unpacking the box, check the outer packaging for damage, such as holes and cracks, and check the equipment model. If you find any damage or the model dose not match your order, do not unpack and contact BIENESOL customer service.


|  |  |  |
|--|--|--|
|   |   |   |
| hybrid inverter  | AC End Cable (2meters) × 1   | Base × 4   |
|  |  |  |
| Dust Plug × 16   | User Manual × 1  | PV Disassembly wrench × 1  |

### Optional accessories


The following accessories must be purchased separately.



## Electric Function



| Name              | Description   |
|-------------------|---|
| WIFI              | Inverter and wireless meter communication antenna   |
| BACK UP<br>ON/OFF | Inverter Back Up switch button, short press for 1 second to turn on Back Up, short press for 2 seconds to turn off BYPASS (when the indicator light is in sleep mode, short press for 30 second to activate the indicator light ) |
| ON/OFF            | Inverter turn on and turn off button  |
| Grid              | Inverter AC grid-connected interface  |

|   |   |
|---|---|
| BACK UP   | Inverter off-grid load port                   |
|  | Inverter external grounding                   |
| COM1  | Inverter Parallel communication com port      |
| COM2  | Inverter Parallel communication com port      |
| COM3  | Inverter host computer communication com port |
| PV1   | Photovoltaic input                            |
| PV2   | Photovoltaic input                            |
| PV3   | Photovoltaic input                            |
| PV4   | Photovoltaic input                            |
| PV1+  | Photovoltaic 1 expansion interface            |
| PV2+  | Photovoltaic 2 expansion interface            |
| PV3+  | Photovoltaic 3 expansion interface            |
| PV4+  | Photovoltaic 4 expansion interface            |

\*  
The voltage of each PV input must not exceed 60V.

## LED Display

| LED Description       | Detailed Explanation  |
|-----------------------|---|
| Blinking Green Light  | Network disconnected  |
| Solid Green Light     | The network connection is normal and the device is operating normally |
| Blinking Red Light    | System failure alarm  |
| White LED Light cycle | Battery charging normally   |
| Solid White Light     | Display current battery level   |
| All LED light cycle   | OTA is updating   |

**Note:** When the device is operating normally and there is no operation, the indicator light will enter the sleeping state after 30 minutes. Press the BACK UP button to reactivate the indicator light.

## Installation


Choose a location for the inverter:

- Avoid electromagnetic interference that may affect the normal operation of electronic equipment;
- Do not install in direct sunlight, near fire sources, or near explosive materials;
- Ensure the installation location is free of potential risks (such as flooding);
- The installation altitude must not exceed 2000 meters;

Measure the installation distance and allow sufficient space for heat dissipation and safe insulation.


## Heavy Object Handling Safety

- When moving the energy storage system pack, be prepared to bear the weight and avoid being crushed or sprained.
- When moving the pack after work, it is recommended that two people lift it together and wear protective gloves to prevent injury.




# Assembly Process

Step 1: Assemble the four wheels




Step 2: Fix Ground wire




# Assembly Process

Step 3: Connect with the solar panels




Step 4: Connect with the grid




## Assembly Process


Step 5: Press ON/OFF button on top the inverter to turn it on.



Step 6: If you need BACK UP output, press BACK UP ON/OFF button.



## Installation Schematic:



## Monitoring System


### Step 1: Download APP

- IOS users: You can search " Bienesol Smart" directly in the Apple APP Store, download and install the software.
- Android users: You can search " Bienesol Smart" directly in Google Play, download and install the software.
- Scan below QR code, download and install the software.



### Step 2: Register and log in

Click " Register", fill in the registration information, and read the " User Agreement" and "Privacy Policy". After completing the registration, log in to your account to use the APP.



## Monitoring System

Step 3: Click " Create Power Plant ", fill in the power plant information, select "HESS" as the Business Type, and complete the power plant creation.

\* Select scene type: Home Storage Home ▾

Image:

Upload

\* Name: 家庭-672

PV Capacity: 0 kWp

Installation date: 2026-01-02 ▾

Address:

China >

上海 >

Please enter the scene address

Revenue: EUR >

Electricity Price: Fixed >


0.5

EUR/kWh

Time zone: GMT+8 ▾

# Monitoring System

Step 4: Turn on Bluetooth, click the "+" sign on the top right corner of the software, wait for the scanned devices to refresh and add devices, and connect to a 2.4G wireless network



# Monitoring System

Step 5: After the device is successfully connected to the network, you can view the device information.

The screenshot displays the BIENESOL monitoring system interface. The top left shows the BIENESOL logo and a dropdown menu for '家庭-672'. Below this is a banner image with the text 'After the sunset, we power on.' A search bar for device names is present, showing 'All(3)' results. Three device cards are visible: BIENESOL0001, RCC5172176, and '我的\_其他'. The right side of the screen shows a detailed view for device BIENESOL0001, including its status (0W), basic information, and a graph of output power over time.

Device:BIENESOL0001  
Data Logger: SXDI625958

| Basic Information                                   |  |
|---|--|
| PV Input Mode<br>Two-way parallel                   | Grid-connected Active Power Dispatch<br>0W |
| System Operating Status<br>Grid connected operation | Output Voltage<br>0.0V                     |
| Output Current<br>0.0A                              | Output Active Power<br>0W                  |

Select Parameters < 2026-01-14 >

W

600  
500  
400  
300

**Note:** Network configuration requires Wi-Fi in the 2.4GHz band. If an error message appears, please check the following possible causes and try again.

- Confirm that the Wi-Fi password is correct and that the Wi-Fi name contains no special characters ( only numbers and letters are supported ).
- Confirm that the Wi-Fi and router are operating only on the 2.4GHz band ( the device does not support the 5GHz band).

- The Wi-Fi signal strength displayed on your phone should be at least 2 bars.
- A router can connect to up to 9 devices ( including the PV hybrid inverter, mobile phone, computer, etc. )
- Ensure that the WLAN ( wireless local area network ) and Bluetooth functions on your phone are enabled.
- Try reducing the distance between your phone and the device. After approximately 60 seconds, the Wi-Fi configuration will be completed, and the PV hybrid inverter system data will be transferred to the server.

## Fault Codes and Troubleshooting

| Code | Fault Information                     | Troubleshooting   |
|------|---------------------------------------|---|
| 1000 | Inverter over voltage                 | The load output voltage is abnormal and this fault will disappear automatically; if the fault persists, please contact service engineer.  |
| 1001 | Inverter under voltage                | The load output voltage is abnormal and this fault will disappear automatically; if the fault persists, please contact service engineer.  |
| 1002 | Inverter over current                 | The standby load is over current. You need to reduce the power consumption of the standby port. This fault will automatically disappear. If the fault persists, please contact service engineer.                    |
| 1004 | Inverter short circuit                | The standby load circuit is short circuited. Check whether the standby port is short circuited. If the fault persists, please contact service engineer.   |
| 1005 | Inverter overload alarm               | The standby load exceeds the rated power. You need to reduce the power consumption of the standby port. The fault will automatically disappear. If the fault persists, please contact service engineer.             |
| 1006 | Inverter overload protection          | Solution is the same as "inverter overload alarm"   |
| 1007 | Inverter fuse abnormality             | The backup side fuse is abnormal. You need to disconnect the photovoltaic and grid connections, and then restart the system. If the fault persists, please contact service engineer.                                |
| 1008 | Inverter relay abnormality            | The backup side replay is abnormal. You need to disconnect the photovoltaic and grid connection, and then restart the system. If the fault persists, please contact service engineer.                               |
| 1016 | Battery over voltage alarm            | The battery voltage exceeds the maximum battery input voltage of the inverter. Check whether the battery voltage is within the rated range of the inverter. If the fault persists, please contact service engineer. |
| 1017 | Battery over voltage protection error | The battery voltage exceeds the maximum battery input voltage of the inverter. Check whether the battery voltage is within the rated range of the inverter. If the fault persists, please contact service engineer. |

|      |   |  |
|------|---|--|
| 1018 | Battery low voltage alarm                           | The battery voltage is lower than the minimum battery input voltage of the inverter. The battery needs to be charged. If the fault persists, please contact service engineer.          |
| 1019 | Battery low voltage protection error                | The battery voltage is lower than the minimum battery input voltage of the inverter. The battery needs to be charged. If the fault persists, please contact service engineer.          |
| 1020 | Battery over current                                | The battery is over current. You need to reduce the power consumption. This fault will automatically disappear. If the fault persists, please contact service engineer.                |
| 1021 | Battery management system (BMS) communication error | The battery and inverter are communicating abnormally. Try to wake up the battery. If the wake up fails, please contact service engineer.  |
| 1040 | AC Grid over voltage                                | The AC power grid is abnormal. The fault will automatically disappear after the power grid returns to normal. If the fault persists, please contact service engineer.                  |
| 1041 | AC Grid under voltage                               | The AC power grid is abnormal. The fault will automatically disappear after the power grid returns to normal. If the fault persists, please contact service engineer.                  |
| 1042 | AC Grid under frequency                             | The AC power grid is abnormal. The fault will automatically disappear after the power grid returns to normal. If the fault persists, please contact service engineer.                  |
| 1043 | AC Grid short circuit                               | The AC power grid is abnormal. The fault will automatically disappear after the power grid returns to normal. If the fault persists, please contact service engineer.                  |
| 1045 | AC Grid overload alarm                              | The AC power grid is overloaded. You need to reduce the number of electrical devices. This fault will automatically disappear. If the fault persists, please contact service engineer. |
| 1046 | AC Grid overload protection                         | The AC power grid is overloaded. You need to reduce the number of electrical devices. This fault will automatically disappear. If the fault persists, please contact service engineer. |
| 1047 | AC Grid fuse error                                  | The grid fuse is abnormal. Disconnect the photovoltaic and grid connections, and then restart the system. If the fault persists, please contact service engineer.                      |

|      |   |   |
|------|---|---|
| 1048 | AC Grid replay error                      | The grid relay is abnormal. Disconnect the photovoltaic and grid connections, and then restart the system. If the fault persists, please contact service engineer.  |
| 1088 | Radiator overheat alarm                   | Check the inverter installation and ensure that the inverter is well cooled. If the fault persists, please contact service engineer.  |
| 1089 | Radiator overheat protection error        | Check the inverter installation and ensure that the inverter is well cooled. If the fault persists, please contact service engineer.  |
| 1090 | Radiator low temperature alarm            | The temperature is lower than the minimum operating temperature of the inverter. Check the installation of the inverter. If the fault persists, please contact service engineer.  |
| 1091 | Radiator low temperature protection error | The temperature is lower than the minimum operating temperature of the inverter. Check the installation of the inverter. If the fault persists, please contact service engineer.  |
| 1092 | Radiator sensor disconnected              | The temperature sensor is abnormal. If the fault persists, please contact service engineer.   |
| 1093 | Internal overheat alarm                   | Check the inverter installation and ensure that the inverter is well cooled. If the fault persists, please contact service engineer.  |
| 1094 | Internal overheat protection error        | Check the inverter installation and ensure that the inverter is well cooled. If the fault persists, please contact service engineer.  |
| 1095 | Internal protection fault                 | There is an internal fault in the device. Disconnect the AC power supply and restart the inverter. If the fault persists, please contact service engineer.  |
| 1105 | Insulation failure                        | Check the insulation of the PV module to the ground, and ensure that the insulation resistance is greater than 200KΩ, ensure that the inverter ground connection is reliable; if the fault persists, please contact service engineer. |
| 1056 | PV1 over current protection error         | Check the photovoltaic module current to ensure it is lower than the maximum DC input current of the inverter. If the fault persists, please contact service engineer.  |
| 1058 | PV1 reverse connection protection error   | The photovoltaic is reversed, so the wiring of PV+ and PV- needs to be swapped.   |

|      |   |  |
|------|---|--|
| 1064 | PV2 over current protection error       | Check the photovoltaic module current to ensure it is lower than the maximum DC input current of the inverter. If the fault persists, please contact service engineer. |
| 1066 | PV2 reverse connection protection error | The photovoltaic is reversed, so the wiring of PV+ and PV- needs to be swapped.  |
| 1072 | PV3 over current protection error       | Check the photovoltaic module current to ensure it is lower than the maximum DC input current of the inverter. If the fault persists, please contact service engineer. |
| 1074 | PV3 reverse connection protection error | The photovoltaic is reversed, so the wiring of PV+ and PV- needs to be swapped.  |
| 1080 | PV3 over current protection error       | Check the photovoltaic module current to ensure it is lower than the maximum DC input current of the inverter. If the fault persists, please contact service engineer. |
| 1082 | PV3 reverse connection protection error | The photovoltaic is reversed, so the wiring of PV+ and PV- needs to be swapped.  |

# Technical Parameters

## Hybrid inverter

| Model                                 | Cube-5200-800                             |
|---------------------------------------|---|
| PV Input (PV)                         |   |
| Recommended Module Power (Wp)         | 300 - 650                                 |
| Quantity of PV Module                 | 1 to 8                                    |
| Max. PV Input Power (W)               | 2500W                                     |
| Startup Voltage @Rated condition (V)  | 22  |
| Operating Voltage Range per Input (V) | 16 - 60                                   |
| Max. Input Voltage per Input (V)      | 60  |
| Nominal Input Voltage (V)             | 42  |
| Short Circuit Current per Input (A)   | 18  |
| Max. Input Current per Input (A)      | 16  |
| AC Port (On-grid)                     |   |
| Nominal AC Output power (VA)          | 800                                       |
| Max. AC Output Power (VA)             | 800                                       |
| Nominal AC Output Current (A)         | 3.5                                       |
| Max. AC Output Current (A)            | 3.5                                       |
| Nominal AC Voltage (V)                | 220/230/240<br>L/N/PE                     |
| Nominal AC Frequency (Hz)             | 50  |
| Power Factor                          | >0.99 default<br>0.8 leading -0.8 lagging |
| THDI                                  | ≤3%@100%<br>Load                          |
| Nominal AC Output Power (W)           | 800                                       |
| AC Port (Off-grid)                    |   |
| Max. AC Output Power (VA)             | 2500                                      |
| Nominal AC Output Power (W)           | 2500                                      |
| Nominal AC Output Current (A)         | 11  |
| Max. AC Output Current (A)            | 11  |

|                                     |                       |
|-------------------------------------|-----------------------|
| Nominal AC Voltage (V)              | 220/230/240<br>L/N/PE |
| Nominal AC Frequency (Hz)           | 50                    |
| Switch Time [ms]                    | < 20                  |
| <b>Efficiency</b>                   |                       |
| Peak Inverter Efficiency            | 94.5%                 |
| MPPT Efficiency                     | 99.9%                 |
| Battery Charge/Discharge Efficiency | 94%/94%               |
| No-load power consumption           | < 25W                 |
| Shut-down and consume electricity   | < 1W                  |
| <b>Battery</b>                      |                       |
| Battery Type                        | LiFePO <sub>4</sub>   |
| Nominal capacity                    | 5120Wh                |
| Nominal voltage                     | 51.2V                 |
| Operation voltage                   | 41.6V-58.4V           |
| Max Standard Current                | 62A                   |
| MAX Discharge Current               | 62A                   |
| Charging temperature                | 0-55°C                |
| Discharge template                  | -20-60°C              |

| Mechanical Data                     |                       |
|-------------------------------------|-----------------------|
| Dimensions (WxHxD mm)               | 630*380*251           |
| Weight ( kg )                       | 62Kg                  |
| General Data                        |                       |
| Communication                       | Wi-Fi/(Bluetooth)     |
| Extra Communication Port            | RS485                 |
| Display                             | SOC Light             |
| Ingress Protection                  | IP65                  |
| Type of Isolation                   | Reinforced insulation |
| Cooling                             | Natural convection    |
| Protection Class                    | I                     |
| Over-voltage Category               | PV II<br>AC III       |
| Operating Ambient Temperature Range | -20 ~ 60℃             |
| Max. Operating Altitude [m]         | 2000                  |
| Relative Humidity                   | 0-95%, Non condensing |

\*Supports a maximum grid-connected output of 2500W

# Maintenance Guide

## Routine Maintenance

- During normal operation, regularly check the environmental conditions and device status to ensure they remain normal. Ensure that the environmental conditions have not changed adversely, the device is not exposed to inclement weather, and is not covered by foreign object.
- If any problems are detected, do not use the device until the fault is corrected and normal conditions are restored.
- The device firmware version can be checked through the monitoring system.
- Avoid unscheduled repairs, use only genuine spare parts for all repairs.

## Battery Pack Maintenance

- Battery maintenance must be performed by or under the supervision of personnel familiar with battery characteristics and related safety precautions.
- When replacing batteries, use only the same type and quantity of batteries.

### **General Instructions for Battery Disassembly and Assembly:**

- Do not dispose of batteries in fire, as this may cause them to expose.
  - Do not open or damage batteries. Leaked electrolyte can damage skin and eyes and may be highly toxic.
  - Batteries pose a risk of electric shock and high short-circuit current. Observe the following precautions when handling batteries.
1. Remove watches, rings, or other metal objects.
  2. Use tools with insulated handles.
  3. Wear rubber gloves and boots.
  4. Do not place metal parts or tools on the battery.
  5. Disconnect the charging power source before connecting or disconnecting the battery terminals.
  6. Check the battery for accidental grounding. If so, remove the grounding source.

## Storage and Disposal

- If the device is not to be used immediately or needs to be stored for an extended period, please check that the packaging is intact. The device should be stored in a well ventilated room, and the environment should be protected from damage to the device components.
- During long-term storage, the product should be charged and discharged every 3 months. Products that have not been charged and discharged for more than 3 months will be void of warranty service.
- If the battery level of the product is extremely low and it has been unused for an extended period, it must be charged before use.
- After an extended period of inactivity, a comprehensive inspection should be performed before restarting the device.
- Upon device decommissioning, it must be properly disposed of in accordance with local regulations, as its components may pose a risk to the environment.
- If conditions permit, fully discharge the battery and place it in a designated battery recycling bin. Batteries containing potentially hazardous chemicals must not be disposed of as regular trash. Please comply with local laws and regulations regarding battery recycling and disposal.
- If a product malfunction prevents the battery from fully discharging, do not place it in a battery recycling bin. Contact a professional battery recycling company for disposal.
- Over-discharged batteries that can not be charged must be properly disposed of.

## Warranty

**Except as expressly provided in this warranty, BIENESOL provided no warranties, express or implied, whether oral or written.**

Damage caused by the following circumstances is not covered by our warranty:

- Transportation damage
- Installation or commissioning by unauthorized dealers.
- Failure to comply with the user manual, repair regulations, and maintenance.
- Modification, alteration, or attempted repair by unauthorized dealers.
- Improper use
- Failure to comply with relevant safety regulations

• Force majeure

1. Our warranty does not cover cosmetic defects that do not directly affect energy output or impair the product's form, fit or functionality.
2. Claims outside the scope of our warranty ( especially claims for direct or indirect damages, disassembly and installation costs, lost profits, etc. ) are not covered by our warranty.
3. In no event shall BIENESOL be liable for personal injury or any other damages ( including direct, indirect, incidental, or consequential damages ) arising from the use of this system, even if BIENESOL has been advised of the possibility of such damages.

## Dealer Responsibilities

If a device malfunctions or issues occur, the dealer is responsible for working directly with the BIENESOL service center to minimize returns for non-faulty devices. The BIENESOL service center will work with the dealer to resolve any malfunctions or fault notifications through telephone support or direct computer connection.

**Note:** To obtain further compensation or a replacement device, the dealer/installer must first contact BIENESOL and follow the instructions to fulfill their dealer/installer responsibilities. During the Data Transfer Unit (DTU) warranty period, service requests the invoice and purchase date, in addition, the product logo must be clearly visible; otherwise, warranty service will be void. For more information, please refer to the BIENESOL Warranty Policy.